


JB06E SHOWER CABIN USER'S GUIDE


1. Mounting Preparation

- 1.) After opening the case, read this instruction carefully, check all the packed parts, and examine the shower cabin for shipping damage. If there is any problem. Please contact the local seller or our company directly in time. You will get a satisfactory answer.
- 2.) Necessary tools: drilling machine, stone drill (D=6mm), meter stick, water level, pencil, screw driver, hammer



- 3.) With structured or imprinted glass make sure that the smooth side of the glass faces the inner side.

2. Packing list



- | | | |
|-----------------------------|----------------------------|--------------------------|
| (1) wall profiles 2pcs | (2) plastic plugs 10pcs | (3) M4x45 screws 10pcs |
| (4) water proof strips 2pcs | (5) Screws cushion (10pcs) | (6) M4x10 screws (10pcs) |
| (7) Screws cover(10pcs) | (8) pivot doors 2pcs | (9) magnet strips (2pcs) |
| | | (10) handle 2pcs |

3. Mounting process

- 1). Put the wall profiles on the walls, keep the distance between profiles and wall is 900mm. adjusting the profiles to make sure it is vertical. Mark the holes on the wall. As FIG.1
- 2). Drilling the holes (10-- $\phi 6\text{mm}$) according the mark, insert the plastic plug into the holes, As FIG. 2.




Fig. 1




Fig. 2

- 3). Fix the wall connecting profiles with M4X45 screws, As FIG. 3




Fig. 3

- 4). Use the M4 X10 screws to connect the pivot doors with the wall profiles. Then, fix it with the magnet strips and handles. As FIG.4. FIG.5




Fig. 4




Fig. 5

- 5). Adjust the screws M4x10, make sure the pivot doors works well. As FIG. 6
- 6). Fix the water proof strips.

